



**NOV 2023** 



## **PRODUCT DATA SHEET**

## NORGLASS LABORATORIES PTY.LTD.

www.norglass.com.au

A.B.N. 92 001 807 245 P.O. Box 312, Neutral Bay. NSW 2089 Australia 59 Moxon Road, Punchbowl NSW Ph: 61 2 9708 2200 Fax: 61 2 9796 3069 Email: norglass@bigpond.net.au



## **CONCRETE & CERAMIC CLEANER**

USES: To clean concrete and ceramic tiles from any organic material.

## PROPERTIES (at 20°C)

**COLOUR:** Clear

**TOXICITY:** See Precautions

FINISH: N/A

**COVERAGE:** Up to 5sq. metres/litre

**DRYING TIME:** N/A

**RECOATING:** N/A

**POT LIFE:** N/A

N/A **MIXING RATIO:** 

THINNING: Not recommended but can be diluted with water.

WEIGHT/LITRE: 1kg

**VOLUME SOLIDS:** N/A

**FLASH POINT:** N/A

**CLEAN UP:** Water **U.N. NUMBER:** 3265

**PREPARATION:** Wash the surface over with fresh water.

**APPLICATION:** Apply the Concrete & Ceramic Cleaner to the surface. Scrub in with a stiff bristle nylon.

brush and leave for 15-20 minutes. If the surface starts to dry off apply more Concrete

Cleaner. Then hose off with full water pressure and allow to dry.

**TRANSPORTATION:** DG Class 8 HAZCHEM 2X P.G.III

SIZES: 1 Litre, 5 litre

**PRECAUTIONS:** Wear protective clothing, goggles and gloves when applying. Where run off occurs into

garden areas, dilute with copious amounts of fresh water or neutralise with a weak

solution of baking soda.

FIRST AID: If poisoning occurs call a doctor or Poisons Information Centre (Aust) on 1311 26 or (NZ)

0800 764 766 and have label information ready.

If swallowed DO NOT induce vomiting. Give large quantities of water or milk. In case of eye contact, flush immediately with plenty of water for at least 15 minutes and consult a doctor. Remove contact lenses if present and easy to do and continue rinsing. In case of skin contact, remove contaminated clothing and wash skin thoroughly. If breathing

difficulty arises remove to fresh air. Apply artificial respiration if not breathing.

**SPECIAL** 

**INSTRUCTIONS:** Keep lid tightly on when not in use and store away from children.