

PRODUCT DATA SHEET

NORGLASS LABORATORIES PTY.LTD.
A.B.N. 92 001 807 245
P.O. Box 312, Neutral Bay. NSW 2089 Australia
59 Moxon Road, Punchbowl NSW
Ph: 61 2 9708 2200 Fax: 61 2 9796 3069
Email: norglass@bigpond.net.au
www.norglass.com.au



MICROTALC

DESCRIPTION: A microfined white powder.

USES: As an extender with epoxy and polyester resins.

PROPERTIES (at 20°C)

APPEARANCE: White

TOXICITY: N/A

FINISH: Flat white

COVERAGE: Varies with resin consistency

DRYING TIME: N/A

RECOATING: Usually next day

POTLIFE: N/A

MIXING RATIO: Normally same volume as mixed resin but can vary widely

THINNING: N/A

WEIGHT/LITRE: 450grams per litre

VOLUME SOLIDS: N/A

FLASH POINT: N/A

CLEAN UP: Norglass Epoxy Thinner

UN NUMBER: N/A

- PREPARATION:** After the resin and hardener have been mixed and blended the Microtalc can then be added using a flat stirrer or spatula until the desired consistency is achieved, then spread the mass onto a large board or palette to reduce the heat generation.
- APPLICATION:** Apply by trowel, squeegee or flat bladed knife.
- TRANSPORTATION:** No special arrangements required.
- PRECAUTIONS:** Wear gloves, goggles and mask when incorporating.
- FIRST AID:** If poisoning occurs call a doctor or Poisons Information Centre (Aust) on 1311 26 or (NZ) 0800 764 766 and have label information ready.
If swallowed DO NOT induce vomiting. Should not cause harm if swallowed. In case of eye contact, flush immediately with plenty of water for at least 15 minutes and consult a doctor. Remove contact lenses if present and easy to do and continue rinsing. In case of skin contact, remove contaminated clothing and wash skin thoroughly. If breathing difficulty arises remove to fresh air. Apply artificial respiration if not breathing.
- SPECIAL INSTRUCTIONS:** N/A