

## PRODUCT DATA SHEET

**NORGLASS LABORATORIES PTY.LTD.**  
A.B.N. 92 001 807 245  
P.O. Box 312, Neutral Bay. NSW 2089 Australia  
59 Moxon Road, Punchbowl NSW  
Ph: 61 2 9708 2200 Fax: 61 2 9796 3069  
Email: [norglass@bigpond.net.au](mailto:norglass@bigpond.net.au)  
[www.norglass.com.au](http://www.norglass.com.au)

### GLUE PROMOTER



**DESCRIPTION:** A blended lightweight extender for Norglass epoxies.

**USES:** To provide a thixotropic glue

#### PROPERTIES (at 20°C)

**COLOUR:** Dry white fluffy Powder

**TOXICITY:** Non Hazardous according to the criteria of Worksafe Australia

**FINISH:** N/A

**COVERAGE:** Varies according to Epoxy Resin mix. Glue consistency.

**DRYING TIME:** 3-4 hours

**RECOATING:** Overnight

**POT LIFE:** Subject to resin volume.

**MIXING RATIO:** 3:1 by vol. Add 60g to 750mls of Norsystem resin base then add 250 mls of fast or slow hardener.

**THINNING:** N/A

**WEIGHT/LITRE:** 60g

**VOLUME SOLIDS:** N/A

**FLASH POINT:** N/A

**CLEAN UP:** NORGLASS EPOXY THINNER

**U.N. NUMBER:** NOT ALLOCATED

- PREPARATION:** Pour 750mls of Norsystem resin base into a plastic pail. Then add in 60g Glue Promoter using a drill and paint stirrer blade, Blend thoroughly and then add in 250mls of Norsystem Hardener.
- APPLICATION:** Apply by trowel or flat bladed knife.
- TRANSPORTATION:** Non Hazardous.
- PRECAUTIONS:** Wear gloves, goggles and mask when incorporating.
- FIRST AID:** If poisoning occurs call a doctor or Poisons Information Centre (Aust) on 1311 26 or (NZ) 0800 764 766 and have label information ready.  
If swallowed DO NOT induce vomiting. Give large quantities of water or milk. In case of eye contact, flush immediately with plenty of water for at least 15 minutes and consult a doctor. Remove contact lenses if present and easy to do and continue rinsing. In case of skin contact, remove contaminated clothing and wash skin thoroughly with soap and water. If breathing difficulty arises remove to fresh air. Apply artificial respiration if not breathing.
- SPECIAL INSTRUCTIONS:** Do not vary the ratio of Norsystem Resin base to Norsystem Slow or Fast Hardeners. The ratio must always be 3:1 by volume.